
Installation Instruction

Three Flow Kitchen Faucet



Replacement Parts


Keep this manual for ordering replacement parts.




NO NAME

- Aerator holder
- Aerator
- O-rina
- Sealing plate
- O-ring
- Spout
- Plastic cover
- O-rina
- O-ring
- Screw
- Faucet body
- Handle knob
- Screw
- Handle body
- Universal fixed cover
- Lock nut
- Cartridge
- Lock nut
- Cartridge holder
- Handle body
- Screw
- Handle knob
- Bottom gasket
- Washer
- Lock nut
- Retainer ring
- Rubber gasket
- 30. Stainless steel gasket
- 31. Hose


Product Dimension Drawing




Faucet Installation Procedures









Step ②








Step ®




Step ⑨




Notice:

Please removing all of the sand, silt and other things from the water hose before assembling, to avoid blocking the faucet and effecting water rate. Please use the special tools to disassemble it and wash with pneumatic equipment, if the faucet blocked.

Step 10



Step ①



Step ①

